
## chipKIT<sup>™</sup> Max32<sup>™</sup> Jumper Settings


Revision: May 23, 2011



The chipKIT<sup>™</sup> Development Platforms are based off the PIC32 Microcontroller. These are 32-bit products that bring unprecedented features to the Arduino<sup>™</sup> community. In order to maintain compatibility with existing hardware/software while maintaining user accessibility to these advanced features, additional jumpers and row headers are provided. This document describes the functionality of the jumpers listed in figure 1.

Figure 1: chipKIT™ Max32 Jumpers







JP3/JP4 SPI SELECT: Used to configure the chipKIT<sup>™</sup> as either a Master or Slave when using the SPI (Serial Peripheral Interface). The chipKIT<sup>™</sup> board can be connected to another device or even another chipKIT<sup>™</sup> through the SPI connector (J13).





chipKIT<sup>™</sup> configured as a SPI Master



chipKIT<sup>™</sup> configured as a SPI Slave

For more information on SPI, please visit Wikipedia's SPI page at: http://en.wikipedia.org/wiki/Serial\_Peripheral\_Interface\_Bus#Mode\_Numbers